



SHIPPENSBURG PUMP CO. INC.

P.O. BOX 279, SHIPPENSBURG, PA 17257

PH 717-532-7321 • FAX 717-532-7704

WWW.SHIPCOPUMPS.COM

Pride

Quality

Craftsmanship

BULLETIN 161

Revised 10/17



**FLASH
RECOVERY UNITS**

TYPE FRV

Flash Recovery Vessel (Vertical)

TYPE FRH

Flash Recovery Vessel (Horizontal)

Steam systems use the vapor phase of water to supply heat or kinetic energy through a piping system. As a source of heat, steam can heat a conditioned space with suitable terminal heat transfer equipment such as fan-coil units, unit heaters, radiators, and convectors (finned tube or cast iron), or steam can heat through a heat exchanger that supplies hot water or some other heat transfer medium to the terminal units. In addition, steam is commonly used in heat exchangers (shell-and-tube, plate, or coil types) to heat domestic hot water and supply heat for industrial and commercial processes such as in laundries and kitchens. Steam is also used as a heat source for certain cooling processes such as single-stage and two-stage absorption refrigeration machines.

Advantages

Steam offers the following advantages:

- Steam flows through the system unaided by external energy sources such as pumps.
- Because of its low density, steam can be used in tall buildings where water systems create excessive pressure.
- Terminal units can be added or removed without making basic changes to the design.
- Steam components can be repaired or replaced by closing the steam supply, without the difficulties associated with draining and refilling a water system.
- Steam is pressure-temperature dependent; therefore, the system temperature can be controlled by varying either steam pressure or temperature.
- Steam can be distributed throughout a heating system with little change in temperature.

In view of these advantages, steam is applicable to the following facilities:

- Where heat is required for process and comfort heating, such as in industrial plants, hospitals, restaurants, dry-cleaning plants, laundries, and commercial buildings.
- Where the heating medium must travel great distances, such as in facilities with scattered building locations, or where the building height would result in excessive pressure in a water system.
- Where intermittent changes in heat load occur.

Fundamentals

Steam is the vapor phase of water and is generated by adding more heat than required to maintain its liquid phase at a given pressure, causing the liquid to change to vapor without any further increase in temperature. Equation 1 illustrates the pressure-temperature relationship and various other properties of steam.

Temperature is the thermal state of both liquid and vapor at any given pressure. The values shown

in Table 1 are for dry saturated steam. The vapor temperature can be raised by adding more heat, resulting in superheated steam, which is used (1) where higher temperatures are required, (2) in large distribution systems to compensate for heat losses and to ensure that steam is delivered at the desired saturated pressure and temperature, and (3) to ensure that the steam is dry and contains no entrained liquid that could damage some turbine-driven equipment.

Enthalpy of the liquid h_f (sensible heat) is the amount of heat in Btu required to raise the temperature of a pound of water from 32°F to the boiling point at the pressure indicated.

Enthalpy of evaporation h_{fg} (latent heat of vaporization) is the amount of heat required to change a pound of boiling water at a given pressure to a pound of steam at the same pressure. This same amount of heat is released when the vapor is condensed back to a liquid.

Enthalpy of the steam h_g (total heat) is the combined enthalpy of liquid and vapor and represents the total heat above 32°F in the steam.

Specific volume, the reciprocal of density, is the volume of unit mass and indicates the volumetric space that 1 lb of steam or water occupies.

An understanding of the above helps explain some of the following unique properties and advantages of steam:

- Most of the heat content of steam is stored as latent heat, which permits large quantities of heat to be transmitted efficiently with little change in temperature. Because the temperature of saturated steam is pressure-dependent, a negligible temperature reduction occurs from the reduction in pressure caused by pipe friction losses as steam flows through the steam. This occurs regardless of the insulation efficiency, as long as the boiler maintains the initial pressure and the steam traps remove the condensate. Conversely, in a hydronic system, inadequate insulation can significantly reduce fluid temperature.
- Steam, as all fluids, flows from areas of high pressure to areas of low pressure and is able to move throughout a system without an external energy source. Heat dissipation causes the vapor to condense, which creates a reduction in pressure caused by the dramatic change in specific volume (1600:1 at atmospheric pressure).
- As steam gives up its latent heat at the terminal equipment, the condensate that forms is initially at the same pressure and temperature as the steam. When this condensate is discharged to a lower pressure (as when a steam trap passes condensate to the return system), the condensate contains more

heat than necessary to maintain the liquid phase at the lower pressure; this excess heat causes some of the liquid to vaporize or "flash" to steam at the lower pressure. The amount of liquid that flashes to steam can be calculated as follows:

$$\% \text{ Flash Steam} = \frac{100(h_{f1} - h_{f2})}{h_{fg2}}$$

where

hf1 = enthalpy of liquid at pressure p1

hf2 = enthalpy of liquid at pressure p2

hfg2 = latent heat of vaporization at pressure p2

Equation 1

Flash steam contains significant and useful heat energy that can be recovered and used (see the section on Heat Recovery). This reevaporation of condensate can be controlled (minimized) by subcooling the condensate within the terminal equipment before it discharges into the return piping. The volume of condensate heat that is subcooling should not be so large as to cause a significant loss of heat transfer (condensing) surface.

Heat Recovery

Two methods are generally employed to recover heat from condensate: (1) the enthalpy of the liquid condensate (sensible heat) can be used to vaporize or "flash" some of the liquid to steam at a lower pressure, or (2) it can be used directly in a heat exchanger to heat air, fluid, or a process.

The particular methods used vary with the type of system. Facilities that purchase steam from a utility generally do not have to return condensate and, therefore, can recover heat to the maximum extent possible. On the other hand, facilities with their own boiler generally want the condensate to return to the boiler as hot as possible, limiting heat recovery because any heat removed from condensate has to be returned to the boiler to generate steam again.

Flash Steam

Flash steam is an effective use for the enthalpy of the liquid condensate. It can be used in any facility that has a requirement for steam at different pressures, regardless of whether steam is purchased or generated by a facility's own boiler. Flash steam can be used in any heat exchange device to heat air, water, or other liquids or directly in processes with lower pressure steam requirements. Equation 1 may be used to calculate the amount of flash steam generated, and Figure 1 provides a graph for calculating the amount of flash steam as a function of system pressures.

Although flash steam can be generated directly by discharging high-pressure condensate to a lower pressure system, most designers prefer a flash tank




Figure 1

to control flashing. Flash tanks can be mounted either vertically or horizontally, but the vertical arrangement shown in Figure 3 (on page 4) is preferred because it provides better separation of steam and water, resulting in the highest possible steam quality.

The most important dimension in the design of vertical flash tanks is the internal diameter, which must be large enough to ensure a low upward velocity of flash to minimize water carryover. If this velocity is low enough, the height of the tank is not important, but it is good practice to use a height of at least 2 to 3 feet. The graph in Figure 2 can be used to determine the internal diameter and is based on a steam velocity of 10 ft/s, which is the maximum velocity in most systems.




Figure 2

Installation is important for proper flash tank operation. Condensate lines should pitch towards the flash tank. If more than one condensate line discharges to the tank, each line should be equipped with a swing check valve to prevent backflow. Condensate lines and the flash tank should be well insulated to prevent any unnecessary heat loss. A thermostatic air vent should be installed at the top of the tank to vent any air that accumulates. The tank should be trapped at the bottom with an inverted bucket or float and thermostatic trap sized to triple the condensate load.

The demand load must always be greater than the amount of flash steam available to prevent the low-pressure system from becoming overpressurized. A safety relief valve should always be installed at the top of the flash tank to preclude such a condition.

Because the flash steam available is generally less than the demand for low-pressure steam, a makeup valve ensures that the low-pressure system maintains design pressure.

Flash tanks are considered pressure vessels and must be constructed in accordance with ASME and local codes.

Rules of thumb:

Horizontal flash tanks should be 2 times tank diameter or 24" minimum length.

Vertical flash tanks should be 3 times tank diameter or 36" minimum length.




Figure 3

Copyright 2008, American Society of Heating, Refrigerating and Air-Conditioning Engineers, Inc. www.ashrae.org. Reprinted by permission from ASHRAE 2008 Handbook-HVAC Systems and Equipment.

LBS/HR

	MAX LOAD	MAX FLASH to 15 PSIG
FRV 6	2,000	500
FRV 8	5,000	1,000
FRV 12	10,000	2,000
FRV 16	20,000	3,000
FRH 6	5,000	500
FRH 8	9,000	1,000
FRH 10	13,000	1,400
FRH 12	20,000	2,000
FRH 16	26,000	3,000